WHITEPAPER

HOW TO CHOOSE A MOBILE ROBOT

FLEET REPEATABILITY AND ACCURACY

INTRODUCTION

You have decided to automate your operation's material handling with autonomous mobile robots (AMRs).

After identifying a few AMRs that have the capacity to carry a sufficient payload for the job, you will want to find some other factors that you can directly compare. If you are looking at datasheets side-by-side, repeatability and accuracy specifications stand out as a place to start. You will see numbers like +/- 10 mm, or +/- 25 mm—but what do these numbers really mean, and why do they matter? Do these numbers mean the same thing on the datasheets of different AMR manufacturers?

Can you be assured that each AMR in your fleet will position itself consistently to reliably pick up or deliver goods from your conveyor systems, exchange a pallet, or perform any number of automation tasks?

In the following sections, we will provide the background needed to properly consider repeatability and accuracy in your AMR selection process.



WHAT'S THE DIFFERENCE BETWEEN "REPEATABILITY" AND "ACCURACY"?

The terms "repeatability" and "accuracy" are often used interchangeably, but the subtle difference between these concepts may have important implications on the reliability of your operations.

REPEATABILITY

<u>ACCURACY</u>

The consistency in which an AMR will return to the same desired location in your facility.

HOW TO CHOOSE A MOBILE ROBOT

A measure of how closely the AMR will align itself with some real-world geometry of interest, for instance, the output of a conveyor line.

The distinction between repeatability and accuracy may not be very important for less demanding AMR applications such as lineside replenishment, manual loading or unloading. However, for many fully automated applications, repeatability is what makes the difference between a hands-off operation and one that requires frequent manual intervention.

When you are comparing AMR specifications, consider:

WHY IS AN AMR'S REPEATABILITY SPECIFICATION SO IMPORTANT?"

Before examining the impact of AMR repeatability on operational reliability, it is helpful to briefly review how AMR's operate. AMRs typically use data from multiple sensor types to compile a digital 'map' of the space they are expected to navigate. As the AMR travels through a facility, it uses those same sensors to update its position on the map. This process is called 'localization.' Common forms of localization compare live sensor data to maps made from scanning lasers, cameras, code readers, or magnetic sensors.



WHAT'S THE DIFFERENCE BETWEEN "REPEATABILITY" AND "ACCURACY"?

Once you have created a map, you will teach goal positions for your AMR. For example, you might manually align your AMR with the output of a conveyor line and add that goal to your map.

Each time the AMR is instructed to return to this goal it will be subject to some localization error. There will always be some measurable deviation from the ideal position due to sensor noise, a dynamic environment, mechanical tolerances, etc. For your operation to be reliable, it is important that this deviation is within your allowable constraints. In this example, it is important that the AMR is aligned well enough with the output conveyor to receive the box, tote, or pallet from the conveyor without jamming or dropping the goods.

If you mark the point on the floor that the AMR positions itself each time it returns to the taught goal for a number of times, you will find a grouping of points. The tightness of this grouping is your AMR's repeatability.

Is the center of that grouping at the exact place where you initially taught the goal? If so, your AMR is both repeatable and accurate at this goal. If your grouping is tight enough for your needs, but the AMR is not aligning well enough with your conveyor, for example, then your AMR may be considered repeatable, but not accurate enough at this location.

Resolving this may be as simple as shifting the taught goal location so that the center of the recorded grouping is in a more accurate location. In practice, measuring and editing locations may quickly become untenable when adding more goals, frequently rearranging your production lines, or most importantly, when adding additional AMRs to your fleet.

IF I HAVE A LARGE FLEET OF AMRS, WILL THEY ALL ARRIVE AT EACH GOAL WITH THIS REPEATABILITY?

Most fleet controllers provide the convenience of sharing a single facility map with an entire fleet of AMRs. This feature comes with the subtle but important consideration that the AMR that made the map will be the most accurate AMR in the fleet. Differences between that AMR and others in the fleet can be attributed to several factors that are difficult to eliminate, including:

Consider again the scatter of points shown in this image. When you instruct each AMR in the fleet to return to the same goal 30 times, you'll likely observe 30 similarly sized groupings. It is unlikely, however, that these groupings will perfectly overlap due to the factors listed on the left. In order to predict the repeatability of a fleet of AMRs it is necessary to account for the data from multiple robots as shown below.



-100



OMROL



100

DISTANCE FROM AVERAGE GOAL POSITION (MM)

-25

-50

AMR Repeatability

It's also important to consider sources of error that aren't represented in the AMR manufacturer's original specifications. For example, if a system integrator builds a conveyor system on each AMR, then the assembly tolerance of the conveyor and its mounting will affect the overall fleet accuracy.

AMR ASSEMBLY TOLERANCES FOR

SENSOR POSITIONS AND WHEEL

LOCATIONS

UNEVEN WHEEL WEAR

IF I HAVE A LARGE FLEET OF AMRS, WILL THEY ALL ARRIVE AT EACH GOAL WITH THIS REPEATABILITY?

A successful demonstration of a single AMR is a good start, but it's

with a value for fleetwide performance.

not necessarily a guarantee that a larger fleet of AMRs will perform as

reliably unless the manufacturer or system provider can also supply you

Conducting a fleetwide repeatability test with multiple AMRs will yield a more trustworthy spec. However, it is not practical to gather data from dozens of AMRs. OMRON recommends testing with four AMRs to confidently asses the repeatability of a larger fleet. We recommend adding more AMRs to the test sample if any unit in the test fleet stands apart as an outlier without showing any recognizable physical defects or sensing problems.



HOW DO AMRS ACHIEVE ALIGNMENT WHERE IT REALLY MATTERS?

Let's return to the conveyor example. If a fleet of AMRs will receive goods from the same conveyor, it is critical that they all align themselves accurately enough for a safe and reliable transfer. If an AMR is too far to the left or right, or if it leaves too large of a gap between the AMR and the conveyor, there's a risk that the transferred goods will be jammed.

Rotational alignment between the AMR and the conveyor is often the most important dimension to consider. A few degrees of misalignment can mean the difference between a successful transfer and delays in your operation.

Some AMRs improve their accuracy at these critical locations with additional sensing that can be used with tape or painted lines, retro-reflectors, bar-codes, or other infrastructure. OMRON offers this type of solution with a peripheral sensing package called High Accuracy Positioning System (HAPS). By carefully placing a magnetic line on the floor, and installing sensors on each AMR, a fleet of LD-60/90 mobile robots will be enabled to stop at a conveyor station within +/- 10mm and +/-0.5 degrees. Individual AMRs, as discussed above, can be expected to outperform this fleet specification.

Another approach to improving local accuracy is to use the AMRs existing sensors to detect known features near the location-of-interest. These features provide a landmark relative to which the AMR can position itself. OMRON has developed the Cell Alignment Positioning System, or CAPS for short. CAPS enables the AMR to use its existing scanning lasers to identify a specific geometry and position itself at destinations where fleetwide repeatability and alignment are crucial. For example, each CAPS-enabled AMR (LD-60/90) in the fleet will position itself within +/- 12 mm, and +/- 0.5° of a user-defined location with respect to that geometry. Single AMRs will outperform this fleet-level specification.

OMRON'S REPEATABILITY TESTING APPROACH

OMRON

Unless otherwise specified, OMRON AMR datasheets state fleetwide specifications as three standard deviations from the fleet's mean position. In other words, a repeatability spec of +/- X mm means that the entire fleet of like robots is expected to arrive within a circle with a radius of X.

Even in a fleet containing different OMRON AMR models, each AMR will share the same map. Each AMR will achieve its specifications, regardless of which AMR type produced the map. A sample of at least four AMRs of each type is tested. Each of these AMRs is tested against maps made by all robot types.

OMRON's test environment is designed to address a broad range of applications, and is based on experience and learning from over a decade of deploying mobile robots in industrial environments. OMRON's test environment includes both mapped features and unmapped obstructions, and is set up to simulate a dynamic production floor.

The reason OMRON rigorously tests fleet repeatability is because that is what matters most to our customers. High repeatability means that robots will consistently arrive to the desired location nad position. There are ways to adjust - or "offset" - the accuracy, but poor repeatability cannot be fixed.



TIPS FOR CONSIDERING KEY FACTORS THAT AFFECT REPEATABILITY

ENVIRONMENTAL DENSITY

In general, an AMR will perform better in places where it has lots of features to localize with than it will in very sparse environments.

NOISY ENVIRONMENTS

The conditions of a repeatability test should be modeled after those of the intended environment. AMRs rely on detecting environmental features like walls and other permanent fixtures. AMR localization will be most accurate immediately after a map is made, before any mapped features have shifted or become obscured. In practice, a productive facility will be changing constantly; pallets full of goods may obscure mapped walls, or people and other vehicles may prevent the AMRs sensors from recognizing as many landmark features.

SHORT TERM TESTING IN A STATIC ENVIRONMENT MAY YIELD OVERLY OPTIMISTIC RESULTS.

OMRON

DIRECTION OF APPROACH

You may find your fleet's positioning accuracy to be better when AMRs always approach a destination from the same direction. This may be caused by differences in environmental factors when approaching from different directions, such as the number of visible features, or the amount that those features are obscured by unmapped obstacles. This may also be caused by AMR-specific factors that lead to a tendency to overshoot or undershoot.



TIPS FOR CONSIDERING KEY FACTORS THAT AFFECT REPEATABILITY

<u>PAYLOAD</u>

Will an AMR yield different repeatability or accuracy data when carrying its full payload capacity than it does when it is unloaded? AMR payload may affect traction or control, and testing should reflect this.



FLOOR CONDITIONS

AMR repeatability may be affected by a floor's flatness, levelness, imperfections, and coefficient of friction. It's important to record the floor conditions when conducting your own tests. Keep the flooring condition of the intended operating environment in mind if your testing will be done in a different space.



SPEED/ACCELERATION

Does meeting the specified accuracy or repeatability spec require using a speed or acceleration different than the AMRs default? If so, this should be specified, especially if the difference is significant enough to impact overall cycle-times or AMR availability.



<u>CONCLUSION</u>

The use of AMRs - once a technical marvel - is starting to become mainstream in factories and warehouses around the world, helping companies sustain and grow without incurring unnecessary cost. We hope this White Paper has helped you understand the importance of fleetwide repeatability and that it will help you mobilize a fleet of AMRs that will quickly and truly benefit your operations.

For more information on AMRs, please visit https://www.omron.com/global/en/



Omron Automation | 800.556.6766 | automation.omron.com

f 🔰 in 🛛 🗗 🕨

Sensing | Control | Safety | Vision | Motion | Robotics

© 2021 Omron. All Rights Reserved.